

Instruction Manual

Multiple Function Data Logger



Introduction

Congratulations on your purchase of this multiple function PDF datalogger.


This datalogger is designed for monitoring temperature, humidity and pressure subject to quality control requirement.

Temperature, humidity and pressure measurements are saved throughout the entire duration of the measurement period.

This datalogger is equipped with a user defined programming function. The measurement report output is implemented using a PDF file and an Excel file, no unique software, and no USB driver are required.

Read through the instruction manual before using this logger. The logger is calibrated before shipment.

Product Description



① USB2.0 plug & play connector. USB driver is not required.

② LED indicator:

Low/High: Red LED blinks every 10 seconds when the measuring set limit value is exceeded during record.

OK: When the logging function is started, the green LED blinks once every 10 seconds when there is no alarm occurs.

③ NTC thermistor for temperature measuring and capacitive humidity sensor for humidity measuring.

④ External probe socket in models with external probe port

⑤ LCD (Liquid Crystal Display).



a. Measured temperature or humidity or pressure.

LCD updates and interexchange every 5 seconds.

b. REC flashes every second when logger is in logging mode. While logger is programmed with start delay, REC displays but doesn't flash during the standby status.

c. T1 is air temperature, T2 is external probe temperature

d. H or L displays when measuring set limit value is exceed.

e. MX or MI display when checking MAX or MIN value from logged data.

f. Low battery icon flashes on display every second when battery level is too low to accurately measure and log data.

⑥ Battery cover, operated by 2 pcs CR2032 batteries. Use coin and follow up the direction indicator to open and close the cover. While installing the batteries, the anode side faces up.

⑦ START/STOP (ON/OFF) key:

After installing the batteries, press key to power on the logger. LCD displays for 2 seconds. Press again to turn off.

After the logger is programmed, press the Start/Stop button for 5 seconds to start logging.

To stop logging, press the Start/Stop button again, for 5 seconds. In the logging mode, short press key won't power off the logger.

⑧ MARK key:

To mark an event manually during the measurement period, press the MARK button for 2 seconds until the measured data flash three times. This MARK function is usually used when there is a transition, from one location to another.

At most 8 marks will be identified in the PDF report.

Short press MARK button any time can also display the leftover battery life time as a quick reference. However, precise battery life time is still decided by operation condition & battery brand.

⑨ MAX/MIN key:

Press key to check the MAX or MIN data of all logged data.

⑩ Waterproof cover and stand:

To provide USB plug waterproof feature, put on this cover and slightly rotate it to make it tight. To make logger stand on desktop, rotate this cover to suitable supporting angle.

⑪ Hanger

Operation

NOTE:

- 1. Adobe Reader software is required.**
- 2. Program the logger and generate the PDF and Excel report at room temperature. For example: if the logger is removed from a freezer, it should be allowed to return to the ambient room temperature before generating the PDF report temperature.**
- 3. The executable file for programming the logger is named: PDF Logger Configuration Tool**

Step1 Configuring the data logger

It is possible to make configuration changes at anytime before the logging function is started. Once the logger is started, configuration changes cannot be made unless stopping the logging first. If the logger is locked with a Password, the Password is required to make configuration changes.

- Press ON/OFF to power on the logger
- Connect the data logger to a PC via the USB port. The green LED is ON while building the connection with computer.
- Windows file display window will appear.
- If the correct file folder is not open, click on Folder to view files.

- Open the file " PDF Logger Configuration Tool.exe".
- The default language is English. The user may change it to one of several alternate languages. There are English, German, French, Italian, Spanish and Portuguese.
- To review the instruction manual, you may click "Manual" to open the manual PDF file.
- The user can check the calibration report for the logger by selecting the PDF file named "Calibration Certificate".
- User programmable parameters are as follows:
 - ★Sampling rate
Select the sampling interval you need from 30 seconds to 2 hours.
 - ★Start delay
Select the start delay from 0 min to 24 hours. For example: If the delay is 5 minutes, and the sampling rate is 10 minutes, the real time to log the first temperature measurement is 5 minutes after the START button is pressed. All measurements after the first measurement will be at a 10 minute (or selected) interval.
 - ★Unit of Measurement (UoM)
Select the unit that will be displayed on the PDF report and LCD. The selections are Metric or Imperial. In Metric, it is Celsius for temperature and hpa for pressure. In Imperial, it is Fahrenheit

for temperature and inHg for pressure.

★Password

The Password function is default OFF. The user may enable it to prevent unauthorized reprogramming prior to pressing the START button. A Password may have up to 16 alpha or numeric characters.

★Company Name

A user defined name, or descriptor, can be input under Company Name. It will be displayed on the PDF report as the Title, with a maximum of 20 characters.

★Alarm types

Regardless of the Alarm Type, if the red LED is triggered, it won't stop even the reading return to normal range or logging is stopped. The way to stop red alarm LED is to plug logger into computer to generate report or power off the logger.

Single: an alarm is triggered immediately when the measured value exceeds the alarm threshold.

Cumulative: an alarm is not triggered when the measured value exceeds the alarm threshold, but only once the overall average value during alarm delay duration exceeds the alarm threshold.

Disable: No alarm function during the logging

process

★Alarm delay

The preset alarm delay interval for a single alarm type is always ZERO.

The adjustable alarm delay interval for a cumulative alarm type can be 5 minutes to 2 hours.

★Alarm Limits

Select the alarm threshold values. For example: if 2 - 8 deg C is selected, it means that an alarm condition will occur below 2 deg C, or above 8 deg C. The programmable alarm limit of each parameter is limited to one decimal. To summarize, to activate a alarm when 30 min average value of hazardous alarm delay period is higher than 8℃, please program the alarm delay as 30 mins, alarm type as cumulative and range as 2~8℃

★Time zone

Before programming the logger the user must assure that the PC is set for the correct time zone. The logger will auto synchronize to the time zone of the PC, when Save is pressed. Time zone changes over the transit distance are not adjusted in the logged data.

The default value of above parameters are:

Sampling rate: 5 min Alarm Type: Disable

Start delay: 0 min Alarm delay: 0 min

Temp. Unit: °C Alarm Limits:

Password: disable Temp. blank

Company Name: blank RH: blank

Language: English Pressure: blank

Once all the programming is done, press "Save"

to confirm the setting and then you may close the

setup window and remove the logger from PC

USB port.

Step2 Start logging

- Press "START" key for 5 seconds when you

want to start the logging.

- "REC" will appear and flash on LCD to indicate

the logging is activated. Measured parameters

update and interexchange on LCD every 10

seconds.

- If Logger is programmed as Start delay, after

pressing the start key, the "REC" will appear (not

flashing) to show the logging is started and in

standby status.

- During the logging, the green LED will blink

every 10 seconds if there is no alarm occurred. If

any, it turns into flashing red LED.

- If the red LED is triggered, it won't stop even the

reading return to normal range or logging is

stopped. The way to stop red alarm LED is to

plug logger into computer to generate report or

power off the logger.

- To place a bookmark manually during the

delivery transition, long press MARK key until

measured reading flashes three times.

- Press MAX/MIN key any time to review the

maximum and minimum data stored in memory.

- Press MARK key can review the approximate

leftover battery life time.

Step3 Download data

- Press "STOP" key for 5 seconds to stop the

logging.

- Plug logger into PC USB port can also stop the

logging.

- Open the file "PDF Logger Configuration Tool.

exe

- Choose function "Convert to PDF" or " Convert

to Excel" to generate the report in preferred

format. The default language is English. The

user may change it to one of several alternate

languages.

- Select the preference location to save the

generated report to.

- The created excel report contains all data

shown in PDF report except the graph.

NOTE: Note: The generated "excel" file is a

tab-delimited ASCII text file which can be

easily read by many programs. However,

when opening the file in Microsoft Excel, a

warning message may be displayed because

the file is named ".csv" but the contents are

like a ".txt" file. It can be safely opened.

Technical data

Model

Model 1 : Temperature logger

Model 2: Temperature + Ext. temp. logger

Model 3: Temperature + Humidity logger

Model 4: Temperature +Humidity +Barometric logger

Temp. & Ext. By NTC thermistor,
measurement -30.0~70.0°C (-22.0~158.0°F)

Temp. resolution 0.1°C (0.1°F)

Temp. accuracy +/-0.5°C

Humidity 0.1~99.9%rH

Humidity res. 0.1%rH

Humidity accu. +/-3% at 25 °C(10-90%rH), others
+/-5%

Barometric 300~1100hpa; 8.9~32.5inHg

Baro res. 1hpa;0.1inHg

Baro accu.(hpa) +/-3(0~60 °C), +/-5 (-20~0 °C), the
rest is not specified.

Logging Type Multiple use

Sampling points

Model 1: 48000 points

Model 2: 24000 Temp. +24000 ext. Temp.

Model 3: 24000 Temp. +24000 Humidity

Model 4: 16000 Temp.+ 16000 Humidity+ 16000 Baro.

Battery Life 3 months

Operating temp. -30~70°C (Logging status); room
temp.(PC status)

Operating RH% Humidity < 80%

Storage temp. -40~85°C

Storage RH% Humidity <90%

Weight ~90g

Battery 2PC 3.0V CR2032

Sampling interval 30 seconds, 5, 10, 30, 60, 90, 120
minutes

Start delay 0, 5, 30, 45, 60, 90,120 minutes,
24 hours

Alarm range Temp: -30.0~70.0°C

Humidity:1~99%rH

Baro:300~1100hpa

Alarm delay 0, 5, 30, 45, 60, 90, 120 minutes

Alarm type Single, Cumulative, Disable

Operation keys 3 Keys, Start/Stop & Mark & MX/Mn

LED indicator REC, High /Low alarm

Protection class

Model 1: IP67

Model 2: IP65

Model 3: IP65, not include sensor

Model 4: IP65, not include sensor.

Directives EN12830

Operating System Windows only

Error Code

| | |
|--|--|
| - - - - . - | |
| Why? | In model 2 only. External probe is unplugged |
| Solution | Check the contact between probe and logger |
| E02 | |
| Why? | Measured value is below specified range |
| Solution | Put the logger in specified range |
| E03 | |
| Why? | Measured value is above specified range |
| Solution | Put the logger in specified range |
| E04 | |
| Why? | In humidity display of model 3 & 4 only, means temperature is in error mode |
| Solution | Solve the error issue of temp. sensor |
| E11 | |
| Why? | In humidity display of model 3 & 4 only, means humidity calibration is fail |
| Solution | Re-calibrate the humidity |
| E31 | |
| Why? | Microprocessor is fail |
| Solution | Contact distributor for after service |
| E33 | |
| Why? | In humidity display of model 3&4 only, means humidity measuring is fail |
| Solution | Contact distributor for after service |
| Why red LED is flashing but recorded data is OK | |
| Why? | Alarm detection works every 10 seconds but data logging are possibly programmed as every 2 hours. In this condition, if alarm happens between two logging points, it might lead the recorded data is OK but red LED is flashing, especially if the alarm mode is set as "Single". |
| Solution | To program the alarm function as cumulative can reduce this situation |